
ZONE INSTALLATION

THE ACOUSTICS COMPANY

The installation guide provided is for the general nature and is designed to assist experienced tradespeople. Please contact your Acoustics Company account manager before you commence


the Installation.



STEP 1



STEP 2




STEP 3



STEP 4



STEP 5



STEP 6











